

<u>Code No.</u>	<u>Description</u>	<u>Drawing No.</u>
AD-09-005	Antenna Bush	A-1989 A
AG-07-021	Handle Chrome	C-1853
AG-07-022	Handle Insert (Modified)	B-1988 A
AG-01-077	Front Panel Painted	D-1923
AG-01-076	Front Panel Chrome	D-1923
AG-11-203	L H Panel Trim	A-1996
AG-11-204	R H Panel Trim	A-1997
AG-11-025	Lower Trim Strip (Barlow Wadley)	A-1998
AD-06-103	Back Vent	
AD-05-401	Loudspeaker Gasket	A-1992
AD-04-815	Dial Scale Backing (Green)	A-1985
AD-04-221	Cam Drum	B-1926
AD-09-007	Cam Drum Bush	B-1927
AD-08-115	Cam Drum Shaft	B-1941
AD-09-009	Clarify Bush	B-1928
AD-08-023	Clarify Shaft	A-1940/B
AD-04-409	Clarify Cord Guide	A-1938
AD-11-012	Speaker Mounting Spacers	A-1939
AA-02-051	P C Board Mounting Fixture	A-1937
AE-01-010	Battery Box "Chitrose"	
AD-01-411	Antenna Coil Mounts	A-1936 A
AG-09-062	Thumbwheel	B-1924
AD-04-201	Dial Drum	B-1925
AD-08-201	Pulley Stud	A-1979
NB-01-201	Back Fixing Screw	A-1978
AA-02-055	Pivot Rod (Card Holder)	B-1931
AG-11-027	Barlow Wadley Badge	A-1999
AE-06-027	External Power Plug	
SA-09-017	Instruction Book	
SA-08-001	Log Card	
SA-11-009	Post Card (Radio/TV Handbook)	
SA-04-001	Frequency Card (Black)	
AE-06-025	Earphone Plug	
NC-02-071	Washer W2 (2mm Flat)	
NC-02-101	Washer SW 2 (2mm Lock)	
AG-01-011	Aerial Yokowa S G 387	
AD-02-001	Spring Clip 1100/8 (Pulley Retaining)	
AD-02-201	Push on Retainer ¼"	
AG-09-061	Black Knob with Embellisher	
NA-02-003	Nut NN2 (2mm) (Micro Switch)	
NB-02-055	Screw M2 x 20 (2mm) (Micro Switch)	
NA-01-301	Rivnut 4 BA (Back Securing)	
AD-07-007	Plastic Pulley 16mm	A-3101
AG-05-001	Rubber Foot	A-1619 A
AD-13-010	Dial Scale Spring	
AD-13-011	Spring (Dial Cord) 28 swg. Closed Coil	
AE-09-021	Micro Switch Omron SS - 5G	
AE-09-208	Band Switch (Mode)	
NC-01-021	Retaining Clip 5 BA Nomel. (Back Screws)	
AG-01-071	Cabinet Trimmed	
AA-02-053	Earphone Socket Mounting Bracket	A-1981
AD-04-721	MHz Drum Scale	A-1984
AD-04-719	KHz Drum Scale	A-1984
AD-11-011	Earphone Socket Bracket Spacer	A-2178/A
NC-01-221	Part Pierced Washer (Ext. Aerial)	A-1983
AA-02-056	Card Holder Tension Plate	A-3009
AD-05-306	Rubber Cushion (Handle)	A-3105
AA-03-027	42 MHz Coil Shield	A-3027
AD-04-413	Cord Guide/Mounting Post	A-2022